


Insta-TEST
 25 Pool & Spa Test Strips
Just DIP & READ!
 Wide Range
pH & Total Chlorine
 LaMotte
 Chestertown, MD 21620 www.lamotte.com/insta




High levels of chlorine (> 15 ppm) will fade the pH reading.

TO USE:
 Immerse test strip and remove with pads face up. **DO NOT SHAKE OFF EXCESS WATER.** Wait 15 seconds and immediately compare to color chart.



- TIPS**
- Keep wet fingers out of the vial.
 - For best results, immerse strip to a depth of 12"-18".
 - Close vial tightly after removing strip.
 - Store in a cool, dry place.



made in USA Code 2987-G